

SCHNIER



Operating manual
Flocking Gun AIR Flocker Pro

Art.Nr.:
810497

Content

1. Product and manufacturer	3
1.1. Product description	3
1.2. Specifications	3
1.3. Product identification	3
1.4. Warranty	3
1.5. Manufacturer	3
2. Guide to this operating manual	4
3. Intended use	4
4. Structure and overview	5
5. Functional description	6
5.1. Commissioning	6
6. Scope of delivery	6
7. Declaration of conformity	7

1. Product and manufacturer

1.1. Product description

The Flocking Gun is pure innovation and inventiveness.

It has a wonderful ergonomic design and size, which makes working much easier. The high-voltage cable is permanently installed in the handle, the air hose can be screwed on directly using the hose adapter supplied and no longer requires a hose clamp. The switch has an optimum pressure point and is particularly durable and robust.

1.2. Specifications

Size (incl. electrodes)	450 x 100 mm
Cable length	4 m / 6 m
weight	1,4 kg

1.3. Product identification

These operating instructions are part of the device:

Product: Flocking gun
Typ: Flocking Gun AIR Flocker Pro
Artikelnummer: 810497 (4m) / 810516 (6m)

1.4. Warranty

The warranty period is 24 months after delivery.
Any type of warranty is void if the appliance has been opened, modified, parts have been replaced with non-original parts or these operating instructions have not been observed.

1.5. Manufacturer

SCHNIER Elektrostatik GmbH

Bayernstr. 13
72768 Reutlingen
Deutschland

Telefon: +49 (0) 71 21 / 90 973 - 60

Fax: +49 (0) 71 21 / 90 973 - 99

www.schnier.de
www.schnier-flock.de
mail@schnier.de

Hauptsitz: Reutlingen HBR 354 531
USt.-IdNr.: DE 146 481 986
Geschäftsführer: Olav Schnier

2. Guide to this operating manual

These operating instructions must be read, understood and observed in all respects by all persons who are responsible for the appliances. Only with knowledge of these operating instructions can errors be avoided and safe and trouble-free operation guaranteed. SCHNIER Elektrostatik GmbH accepts no liability for damage resulting from non-compliance with these operating instructions!

3. Intended use

This device is intended exclusively for use as a hand cable for flocking.



ATTENTION


Any commissioning outside this provision is prohibited.

Damages / Modifications:



No structural modifications of any kind may be made to this device.

4. Structure and overview



- 1 Contacts for electrodes
- 2 Connection for air hose
- 3 HV-cable
- 4 Union nut
- 5 HV connector plug

5. Functional description

5.1. Commissioning

- Plug HV-connector plug [5] of the hand cable into the high-voltage connection of your device (Fig. 1).
- Please tighten the union nut [4] only slightly
- Screw the air hose onto the hose connection and connect it to the HV cable using cable ties.
- Connect the wire from the hose for grounding to the earth socket of the AIR Flocker Pro.
- Place the hose over the connection on the AIR Flocker Pro and secure with the hose clamp.
- As soon as the button is pressed, the high voltage is switched on.



The HV connector plug must always be clean and dry. Moisture and dirt damage the devices.



Abb. 1

6. Scope of delivery

- Flocking Gun AIR Flocker

The electrode set is not included in the scope of delivery and must be ordered separately.

7. Declaration of conformity

Manufacturer: SCHNIER Elektrostatik GmbH
Bayernstrasse 13
D-72768 Reutlingen

Product: Flocking cable
Type: Flocking Gun AIR Flocker Pro
SCHNIER Art.-Nr.: 810497
Trade name: Flocking Gun AIR Flocker Pro
Function: Hand cable for use in electrostatic and pneumatic flocking

Rommelsbach 06.09.2022



Olav Schnier (CEO)